



Package contents

- 1 x eNetMini-2105-1
 - 4 x Spacer
 - 1 x Quickguide
 - 1 x Label with mDNS-Address
- Optional:
- 1 x Magnet
 - 1 x Housing (housing base, housing cover, sensor cover)

This quick guide provides the most important information on operating the eNetMini in a compact format.



Further descriptions can be found on our homepage at www.enetmini.com

Delivery status

Netzwerk, RJ45, 10/100 MBit	
IP-Address, IP-Mask ¹	DHCP (192.168.015.100 / 24)
mDNS- Address	Label
Administrator username ¹	user_su
Administrator password ¹	pass_su

¹ Changeable

Recycling

	To minimize its environmental impact, the product must be treated in accordance with European Directive 2012/19/EU in order to be recycled or dismantled. The user has the choice of returning the product to a competent recycling organization or to the retailer when purchasing a new electrical or electronic device.
--	--

Conformity

	CE Note: When used in a private environment, the product may cause electromagnetic interference
	RoHS compliant
	REACH compliant



Further information on our products and services can be found at www.mkc-gmbh.com




eNetMini-2105-1

Quickguide

Safety notes

Please read and follow the following safety instructions when using the appliance.

We cannot guarantee that improper use of the appliance will not result in accidents or damage. Please use this product with care and at your own risk.

	Keep the device away from water, fire, moisture or hot environments.
	Do not attempt to disassemble, repair or modify the device.
	Do not use damaged cables with the device.
	Do not operate the device outside the device specifications.

Assembly

Before commissioning the eNetMini, ensure that it is securely positioned or fastened.

To do this, insert the four spacers into the holes provided and screw it down if necessary. Alternatively, you can use a separately purchased housing.


The eNetMini can be operated in all positions. However, precise alignment may be required for the desired functionality of the sensors.

When installing the network cable, make sure that the plug snaps into the socket.

Orientation

The motion detector and ambient light sensor should be aligned in the direction of the source to be measured.

The more vertically the light rays fall on the light sensor, the stronger the deflection.



Positioning

The measured temperature and humidity values may deviate from the environment if the circuit board is placed in a location without air circulation.

Furthermore, an air flow that is directed straight at the pressure sensor can falsify the measurement.